

OPERATOR PROGRAMMING Siemens Hicom / HiPath

TO START PROGRAMMING

1. Leave handset down and Dial * 951 √√

SELECTING YOUR CHOICE FROM THE MENU

Press ◀ ▶ to scroll to your choice

Press √ to confirm your selection

	Speed Dialing
	Set Time
	Set
	Extension Names

OPTIONS

- | | | |
|-------------|--------------|---|
| √ on | NEXT | Scrolls forwards to a desired selection |
| + and - | Volume keys | Scroll forward and backward |
| Select name | | Searches a desired speed dial number or extension |
| √ on | CHANGE ENTRY | To enter speed dial number or extension name |

ENTERING ALPHA CHARACTERS

- ⬆ While held down with a letter produces capitals
- ⬅ Deletes characters

EXITING PROGRAMMING

Press either SERVICE or SPEAKER key